

Consolidated Activation Methods and Outlets of all Models of FirePro Generators

Extinguishing units	BTA activation	Electrical activation	Manual activation (by pulling a pin on the unit)	Outlets	Article No
Cylindrical					
FP-20 SE	no	yes	no	2	10135
FP-20 T	no	yes	no	1	10620
FP-20 TH	yes	no	no	1	10649
FP-40 S	no	yes	no	2	10136
FP-40 T	yes	yes	no	1	10609
FP-80 S	no	yes	no	2	10138
FP-80 T	yes	yes	no	1	10617
FP-100 S	yes	yes	no	1	10140
FP-200 S	yes	yes	no	1	10142
FP-500 S	yes	yes	no	1	10145
Box-type Carbon Steel					
FP-1200	no	yes	no	1	10147
FP-1200 T	yes	yes	no	1	10316
FP-2000	no	yes	no	1	10149
FP-2000 T	yes	yes	no	1	10317
FP-3000	no	yes	no	1	10150
FP-3000 T	yes	yes	no	1	10318
FP-4200 T	yes	yes	no	1	10338
FP-5700	no	yes	no	1	10151
FP-5700 T	yes	yes	no	1	10319
Box-type SS					
FP-1200 S	no	yes	no	1	10395
FP-1200 TS	yes	yes	no	1	10622
FP-2000 S	no	yes	no	1	10392
FP-2000 TS	yes	yes	no	1	10623
FP-3000 S	no	yes	no	1	10393
FP-3000 TS	yes	yes	no	1	10624
FP-4200 TS	yes	yes	no	1	10644
FP-5700 S	no	yes	no	1	10391
FP-5700 TS	yes	yes	no	1	10625
Manual operating units					
FP-200M	no	no	yes	1	10143
FP-500M	no	no	yes	1	10347
FP-1000M	no	no	yes	2	10146